



PAGING SYSTEM DIAGRAM (1/1/92)




NOTE: IF MICROPHONE PRE-AMP. IS NOT USED, THE OUTPUT "B" OF THE A/B SWITCHER MUST BE CONNECTED TO THE PAGE MIC. (XLR JACK) OF THE MAIN SYMETRIX.

IF MICROPHONE PRE-AMP. IS USED, THE OUTPUT "B" OF THE A/B SWITCHER MUST BE CONNECTED TO THE HOUSE PAGE IN TERMINALS OF THE MAIN SYMETRIX.

571 SPL SYMETRIX



~~Order 27~~



W#27



W#28



W#26

P.B. CAB